PARTS LIST

for

KitchenAid®

30" ELECTRIC DROP-IN SELF CLEAN RANGE

MODEL KEDT105V<u>BL</u>0

> ▲ BL-Black Glass WH-White Glass AL-Almond Glass



FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS




KITCHENAID INC.

© 1990 WHIRLPOOL CORPORATION

ST. JOSEPH MICHIGAN 49085

COOKTOP PARTS

For Model: KEDT105VBL0




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

```
NOTE: The screws and nuts required to attach a part are listed immediately
following that part.
      3147132
                   Surface Unit, 8" (2)
1
      3147131
                   Surface Unit, 6" (2)
2
                  Ring, Intermediate
      3147186
                  Black 8"
                  White 8"
      3148489
                  Almond
                               8 "
      3148490
      3147185
                  Black 6"
      3148486
                  White 6"
      3148487
                  Almond 6"
3
                  Gasket (2)
      3147188
                  8"
      3147187
                  6"
5
                  Glass Top
      3148036
                  Black
      3148591
                  White
      3148592
                  Almond
                  8" Seal (2)
6
      3148561
                  6" Seal (2)
      3148562
7
      3148563
                  Hook, Seal (4)
8
      3147038
                  Plate, Backup
9
      3147735
                  Bracket, Switch
      254225
                  Screw \#8x1/4 (3)
10
                  Switch, Infinite
      3148949
                  6"
                  8"
      3148950
      311865
                   Screw #8-32 (8)
11
      309839
                   Seal, Shaft (4)
12
                  Tape, Foam
      3147485
13
                  Bracket, Mounting
      3147703
                   6"
      3147704
                  8"
                  SPST Thermostat
14
      3148397
15
      3147190
                  Nut (4)
16
      3147191
                  Leaf Spring (4)
      3148615
                  Washer, Flat (4)
17
      3147189
                  Nut (4)
                  Lens, Amber (4)
18
      311688
19
                  Rail, Support
      3147024
                  Left
      3147025
                  Right
      3147061
                  Rail, Support Front & Rear (2)
20
                  Screw, 8-18 \times 1/2
      313638
21
      3149116
                  Knob, Control (4)
22
      3147566
                  Cover, Top Rear
      313638
                   Screw, 8-18 (3)
23
      258109
                  Bushing
24
      3148054
                   Indicator, Light
26
                  Cover, Vent
      3147037
                   Seal, Infinate Switch (4)
27
      3149899
LITERATURE PARTS
      LIT3148392 Tech Sheet
      LIT3147380 Instructions, Installation
      LIT3147429 Guide, Use & Care
      LIT3147469 Book, Cooking Guide
                  List, Repair Parts
```


LIT884800

CONTROL PANEL PARTS For Model: KEDT105VBL0



Note: The Screws And Nuts Required To Attach A Part Are Listed Immediately Following That Part.

```
End Cap, L.H.
1
      3148016
                  Black
                  White
      3148447
      3148449
                  Almond End Cap R.H.
      3148017
                  Black
      3148448
                  White
      3148450
                  Almond
                  Washer, Silicone
      3148905
2
                  Glass, Control Panel
                  Black
      3148769
                  White
      3148459
      3148460
                  Almond
3
      314240
                  Rail, Top
                  Trim, Center
4
      3149420
                  End Trim, R.H. Vent Door
5
      3148698
                  Black
      3148472
                  White - Almond End Trim, L.H. Vent Door
      3148697
                  Black
      3148471
                  White - Almond
6
                  Vent Door
      314190
                  Black
                  White - Almond
      3149676
      314184
                  Trim, Bottom
      342043
                  Screw (6)
8
      310842
                  Channel, Rubber (2)
9
      310823
                  Retainer, Glass (4)
10
      310720
                  Bracket, Control Panel (2)
      98520
                  Screw (4)
12
      3148647
                  Bracket, Control
13
      3149045
                  Oven Control
      313806
                  Screw #6-32 (4)
      3149648
                  Thermostat, Oven
17
      313808
                  Screw \#6-32x9/32 (2)
20
                  Switch, Oven Light
      312581
                  Black
                  White - Almond
      3148465
      312796
                  Washer
21
      313030
                  Bezel, Switch
                  Screw
      246132
26
      3149046
                  Knob, Timer (1)
31
      3148102
                  Brace, Control Bracket
                  Button, Set (8)
32
      3149040
                  Trim, End Cap
33
      314246
      3149329
                  White
      3149330
                  Almond
                  Shield - Air
34
      3149142
35
      3149419
                  Shield - Heat
```




```
t:Note: The Screws And Nuts Required To Attach A Part Are Listed Immediately Following That Part.
```

```
3170855
                   Front Frame
2
      307985
                   Pin, Hinge Ear (2)
3
      309111
                   Snubber, Door (2)
4
                   Pushnut (2)
      308306
5
                   Insulation Tray
      310770
      311006
                   Side Wrapper R.H.
6
      311009
                   Side Wrapper L.H.
7
      311774
                   Support, Side Wrapper (4)
      3148107
                   Screw (4)
                   Insulation Baffle (2)
8
      311256
      3148442
                   Screw (2)
9
      310693
                   Baffle, Top Insulation
      3148107
                   Screw,
                   Side Trim L.H.
10
      310685
                   Side Trim R.H.
      310689
      3148107
                   Screw,
11
      329003
                   Oven, Main
      311056
                   Screw (3)
12
      310713
                   Bracket,
                               Oven Mounting (2)
      343641
                   Screw (6)
                   Plug Button
13
      257314
                   Hinge Ear R.H.
15
      328801
      328802
                   Hinge Ear L.H.
16
      310659
                   Plate (Side Panel) (2)
                   Screw (4)
      308544
17
      329713
                   Channel Arm (2)
18
      307986
                   Pin, Hinge (2)
19
                   Ring, Retainer (2)
      307594
      312320
                   Shield, Insulation
20
      307748
                   Screw
21
      308125
                   Anchor, Spring (2)
22
      308126
                   Spring, Oven Door (2)
23
      3147220
                   Tube, Vent Extension
      343641
                   Screw
                   Smoke Eliminator
24
      310839
      3148107
                   Screw (2)
25
                   Plate, Cover
      310662
      3148107
                   Screw (2)
                   Unit, Bake 308180 (Alt.) 313827 (Alt.)
26
      661170
      246127
                   Screw (2)
      3148040
                   Unit, Broil
2.7
                   Screw (4)
      246127
28
      660556
                   Socket, Oven Light
      308043
                   Screw (2) 10-12 \times 7/8 (2)
29
      311255
                   Bulb, Oven Light
30
                   Cover, Oven Light
      308039
31
      308038
                   Retainer, Oven Light
32
      311982
                   Coverplate
                   Screw (2)
      3148107
      246127
                   Screw
33
      3171150
                   Latch Assembly
      313638
                   Screw (2)
      311056
                   Screw (2)
34
      313309
                   Safety Switch
      98106
                   Screw (2)
```


```
35
      309245
                  Insulator, Switch
36
      313035
                  Terminal, Shield
      309258
                  Screw (2)
      3148107
                  Screw (2)
37
      310825
                  Latch Handle
      308422
                  Screw (2)
      311253
                  Knob, Latch Handle
38
      246135
                  Screw
39
      310345
                  Switch, Door
      3148107
                  Screw (2)
40
      3148284
                  Seal
45
      3148440
                  Sensor
      3148107
                  Screw (2)
46
                  Side Trim Left Hand
      3149426
                  Black
      3149428
                  White
                  Almond Side Trim Right Hand
      3149430
      3149427
                  Black
      3149429
                  White
      3149431
                  Almond
      355515
                  Screw (4)
47
                  Bottom Vent
      3149446
                  Black
      3149447
                  White
      3149448
                  Almond
48
      3149458
                  Bracket, Mounting
                  Screw Black (2)
      3149333
                  Clip Mounting (2)
      314235
                  Back Panel
52
      3149542
      3148107
                  Screw (12)
                  Terminal Block
53
      258076
      112432
                  Nut (3)
      308043
                  Screw (2)
54
      310458
                  Cover, Bottom & Top
55
      311592
                  Angle, Support (2)
                  Screw (4)
      3148107
                  Cover, Rear
56
      311012
                  Screw (12)
      3148107
                  Pan, Broiler
Grid, Broiler Pan
59
      3147845
60
      3147563
61
      308173
                  Rack, Oven
62
      308172
                  Rack, Oven Offset
```

WIRING HARNESS PARTS For Model: KEDT105VBL0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

```
1 3149770 Harness, Wire (Main)
2 3147825 Harness, Wire (suface Unit)
3 3147269 Harness, Wire (Infinite Switch)
```



```
1
      3170706
                  Liner, Door
                  Screw (6)
      3148443
2
                  Frame, Window
      3148234
      3148443
                   Screw, (6)
3
      3148441
                  Seal, Flange (2)
      3148443
                  Screw (4)
4
      3148178
                  Glass, Reflective
5
      3148183
                  Seal, Window
                  Retainer, Insulation
6
      3148723
                  Screw (4)
      3148443
7
      313004
                  Glass, Inner
                  Retainer, Glass (2)
8
      3148187
9
      3148182
                  Bumper, (4)
10
                  Glass, Panel
                  Black
      3148185
      3149049
                  White
      3149050
                  Almond
11
      3148184
                  Foil
12
                  Handle, Oven Door
      3147636
                  Black
                  White
      3147637
      3147638
                  Almond
      355515
                  Screw (4)
13
      3147951
                  Insulation
                  Cap, Top White - Almond Clip, Mtg. (2)
14
      3149473
15
      314235
      3148680
                  Shield
16
      254225
                   Screw (2)
17
                  Glass, Outer
      313005
18
                  Frame
                  Black
      3148784
      3148785
                  White
      3148786
                  Almond
19
                  Door Top
      3148606
                  Black
      3149675
                  White - Almond
      3149333
                  Screw (5) Black
                  Screw (2) White - Almond
      9416643
```